




Nanny Panel Playpen

Assembly Guide





Ensure both surfaces of the panels are touching and flat.



When assembling, place playpen on a hard tiled or wood floors, not carpet, and push firmly downwards until you hear panels click into place.

surface such as

When setting up, ensure the logo is facing outwards, the as installing panels logo side inwards, can cause damage and breakage to pins.



WARNING



This is not a safety device
DO NOT LEAVE CHILDREN UNATTENDED
DO NOT use as a barrier for stairways, stoves or heaters
Incorrect installation may result in instability & weakness
Keep plastic bags away from children

EXPORTER

TikkTokk HONG KONG
Room 50 45F Premier Centre,
No.20 Cheung Shun Street,
Cheung Sha Wan,
Kowloon, Hong Kong

CONSUMER ASSISTANCE

HOTLINE: +61 (0) 2 9980 6633
SKYPE: tikktokk.mb
EMAIL: info@tikktokk.com
WEB: www.tikktokk.com
ADDRESS: Unit 3, 280 New Line Rd,
Dural, NSW, 2158,
Australia

www.tikktokk.com

PRODUCT NOTICE



The finish deteriorates if over exposed to the elements
Colours, especially red deteriorate or alter in strong
sunlight
Be sure to check all Safety Notices on the side of the
carton

IMPORTER

TikkTokk Australia
Unit 3, 280 New Line Rd
Dural, NSW, 2158
Australia

NPPP01 / NPPP81