


# Grotime®

## MARSEILLE CHEST 33130



Follow all manufacturer's assembly instructions carefully to ensure the safety features to the chest are not compromised

### Grotime

110-114 Old Bathurst Rd,  
Emu Plains, NSW 2750

P.O. Box 487, Emu Plains,  
NSW 2750

### Customer Care

**Email:** [customercare@grotime.com.au](mailto:customercare@grotime.com.au)


AUSTRALIA  
1300 799 912  
[www.grotime.com.au](http://www.grotime.com.au)

NEW ZEALAND  
+61 2 4728 8067  
[www.grotime.co.nz](http://www.grotime.co.nz)



Carefully remove all packaging material and dispose of it according to grade. Be careful not to throw away any components by mistake. After use, dispose of the product in an environmentally friendly manner at your local recycling centre

## HARDWARE INVENTORY



x8

55mm bolt



x1

Allen key



x4


Wooden dowel



x8

35mm bolt

## PARTS INVENTORY



x2

Changer-top  
side panel




x1

Changer-top  
front panel




x1

Changer- top  
back panel



x2

Connecting rail



x1



Plinth end panel pair

### **WARNING**

BEFORE ASSEMBLING THE CHEST,  
ENSURE YOU HAVE A CLEAR AREA ON  
CARPET OR A THICK BLANKET OR RUG.  
NEVER ASSEMBLE ON A HARD SURFACE.



## STEP 1

Assemble change table and attach to chest  
using 4 x wooden dowels and 8 x 35mm bolts





## STEP 2

Assemble plinth end panels with rails



### STEP 3

Join chest base to chest using 8 x55mm bolts  
(2 screws sandwich each corner of the plinth)




## **WARNING**

WE STRONGLY RECOMMEND THAT THIS PRODUCT BE PERMANENTLY FIXED TO THE WALL OR OTHER SUITABLE SURFACE. PLEASE SEEK PROFESSIONAL ADVICE IF YOU ARE IN DOUBT WHAT FIXING DEVICE TO USE.

### STEP 4

There is an anti-topple fixed to the back of the chest.  
Choose a suitable wall fixing and then fasten the strap to the wall as shown using appropriate fixings.



### **FURNITURE TRIP-OVER HAZARDS**

Children like climbing on things, especially if there is something up high that they want. Household furniture like bookshelves, chests of drawers and entertainment units can be attractive to climb. So too furniture like tallboys where pulled-out drawers act as stairs for climbing.

The inclusion of the anchoring strap is supplied as per the recommendations of the Best Practice Guide for Furniture and Television Trip-Over Prevention, from the National Retail Association.

## MAINTENANCE AND CARE

Check your chest regularly. Re-tighten all bolts. For customer care contact Grotime Australia on 1300 799 912; or New Zealand on +61 2 4728 8067.

Do not use abrasive or corrosive agents, or hard brushes for cleaning.

Clean the surface with a lightly dampened, lint free cloth and then wipe with a dry cloth

## USAGE

This chest is suitable for indoor use only. Please protect it from moisture.

The chest is intended for a private household, and is unsuitable for commercial purposes.

## 5 YEAR NURSERY FURNITURE WARRANTY

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. In order for your claim to be processed in an efficient timely manner please follow the warranty claims process as outlined below:
  - Fill in the online customer service form found on the following link:  
<https://grotime.com.au/customer-service-and-warranty-claims>
  - If you are unable for any reason to process your warranty claim using the online customer care form please call our Grotime customer care team on AU - 1300 799 912 NZ - +61 2 4728 8076 or email [customercare@grotime.com.au](mailto:customercare@grotime.com.au)
  - In order for your claim to be processed you will need to provide to Grotime with an original proof of purchase. For example original retailer purchase receipt, bill of sale, invoice, lay-by docket, credit card receipt or similar proof of purchase.
  - Note: providing attached photographs with your claim will greatly enhance the speed in which your claim is processed.
3. This warranty does not obligate Grotime to bear transportation costs incurred in the repair or replacement of any defective parts and excludes any superficial scratches, dents, scrapes or blemishes to paint work or timber surfaces. This Warranty does not cover faults or defects caused by:
  - unsuitable, improper use or use not in accordance with the manufacturer's specifications
  - incorrect installation or installation not in accordance with instructions provided
  - normal wear and tear
  - inadequate or complete lack of maintenance
  - chemical, electrochemical or electrical influences or harsh detergents or abrasive cleaners used on product finishes
  - discolouration caused to timber finish by ultra violet (UV) rays or overexposure to direct sunlight
4. To the fullest extent permitted by law, Grotime excludes all liability for damage or injury to any person, damage to any property, and any indirect consequential or other loss or damage.